



METAL WINDOW LOCK

ref 901

To fit a Metal Window Lock you will require -

a drill, 3.5mm drill bit, posidriv screwdriver, pencil and masking tape.

- ◀ Indicates lock position.
- ◀ Alternative positions for greater security.

Easy fitting guide

A Close window and select position of Metal Window Lock.

B Position lock mechanism on opening window frame. Leave a 3mm gap from the fixed window frame.

Ensure clearance when opening window. Mark position of screw holes.

C Apply masking tape to drill bit and drill holes to 4mm depth.

Caution: ensure that drill bit will not touch glass. Screw lock mechanism onto frame.

Operation - turn key clockwise to lock and anti-clockwise to open.

Crime prevention tip - for extra security, drill out the drive slots in screw head. (We recommend fitting locks to top hinged windows).

Maintenance - use a moist cloth only to clean all types of finish, household abrasives or solvents may affect the surface finish.

