

King Pin Lock Fitting Instructions



1. Remove the black PVC cover.
2. Remove the lock bar from the King Pin Lock by inserting key, rotating 1/4 turn anti-clockwise, and withdraw lock.
3. Offer the casting up to the King Pin, insert the lock bar, and rotate key 1/4 turn clockwise to lock.

TIP

If the shallow PVC cover is left under the King Pin casting as the lock is fitted and removed this will prevent grease getting on your hands.

We have taken every care in the design and manufacture of this security device and we believe that it is an effective deterrent. However we cannot guarantee that it will resist the efforts of the most determined thief, and as such we do not accept any liability for loss or damage caused by theft, vandalism or other illegal activity against property to which this device is fitted.

Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray outside of lock body with WD40 (or equivalent) minimum every four months.

Key Security. Enter your key number here:

IMPORTANT - Your Bulldog product is supplied with two keys. Make a note of your personal key number in the space provided above and **keep it in a safe place.** Should you lose your keys, replacements can only be obtained from the manufacturer through your dealer.